
Apollo

DATA SHEET

Zirconia O₂ Sensors Probe Series—Short Housing

- Zirconium dioxide (ZrO₂) sensing elements
- Long life, non-depleting technology
- Integral heating element
- High accuracy
- Requires an external interface board to operate¹





BENEFITS

- No reference gas required
- No need for temperature stabilisation
- Compact enclosure

TECHNICAL SPECIFICATIONS

Heater voltage²

i ionago	
Operating (standard response)	$4V_{DC} \pm 0.1V_{DC}$ (1.7A)
Standby	1.65V _{DC} (0.7A)
Operating (fast response)	$4.35V_{DC} \pm 0.1V_{DC}$ (1.85A)
Standby	2V _{DC} (0.85A)
Pump impedance at 700°C ³	< 6kΩ
Permissible gas temperature	-100°C to +250°C
Gas flow rate	0—10 m/s
Repetitive permissible acceleration	5g
Incidental permissible acceleration	30g

2) 3)

OUTPUT VALUES

Oxygen pressure range	2mbar—3bar max
Accuracy	5mbar max
Internal operational temperature	700°C
Response time (10—90% step)	
Standard response sensor	< 15s
Fast response sensor	< 4s
Warm up time (prior to sensor operation)	60s
Warm up time (from standby)	20s
Output stabilisation time	~ 180s

Interface board sold separately.

It is important to measure the heater voltage as close to the sensor as possible due to voltage drops in the supply cable. The constant current source used in the pump circuit should be designed to drive a load of up to $6k\Omega$.

Apollosense Ltd

Shenzhen

Adress : Room 712, Huaneng Building, Shennan Zhong Road, Shenzhen 518031, China Tel : (86-755) 83680810 83680820 83680830 83680860

NOTES


Fax: (86-755)83680866

Hong Kong: Adress : Unit 1502, Hollywood Plaza, 610 Nathan Road, Mong Kok, Kln., H.K. Tel : (852) 2737 0903 Fax : (852) 2737 0938 Email : sales@apollounion.com




UTLINE DRAWING

All dimensions shown in mm.






Molex Connector



Pin	Designation
1	Pump (Red)
2	Common (Black)
3	Heater (1) (Yellow)
4	Sense (Blue)
5	Heater (2) (Yellow)

Generate your specific part number using the convention shown below. Use only those letters and numbers that correspond to the sensor options you require — omit those you do not.



Do not exceed maximum ratings and ensure sensor(s) are operated in accordance with their requirements. Carefully follow all wiring instructions. Incorrect wiring can cause permanent damage to the device. Zirconium dioxide sensors are damaged by the presence of silicone.	INFORMATION s customer applications are outside of Apollosense Ltd.'s control, the formation provided is given without legal responsibility. Customers should use under their own conditions to ensure that the equipment is suitable for heir intended application. or detailed information on the sensor operation refer to application note N0043 Operating Principle and Construction of Zirconium Dioxide Oxygen ensors.
--	---

General Note: Apollosense Ltd. reserves the right to make changes to product specifications without notice or liability. All information is subject toApollosense Ltd.'s own data and considered accurate at time of going to print.

Apollosense Ltd

Shenzhen: Adress : Room 712, Huaneng Building, Shennan Zhong Road, Shenzhen 518031, China Tel : (86-755) 83680810 83680820 83680830 83680860 Fax : (86-755) 83680866 Hong Kong: Adress : Unit 1502, Hollywood Plaza, 610 Nathan Road, Mong Kok, Kln., H.K. Tel : (852) 2737 0903 Fax : (852) 2737 0938 Email : sales@apollounion.com